

Brand	Machine	Color	Product Code	Cartridge Type	Recommended for use In	OPC Drum	Toner	Carrier & Developer	Chips
Samsung	Printer	Color	S300C	CLP300RA / 108R00744	CLP 300, CLP310,315 CLX 2161, 3161 Xerox Phaser 6110	○	○		○
		Mono	SU-V3	ML4500D,1710D,1210D ML2250D,ML2010D,1610D MLT D1082S,MLT 1092S SCX 4521D	ML 700,1010,1020,1210,1220,1250,1430 ML 1510,1710,1720,1740,1750,1755 ML 4500,4600,5000,5080,6000 ML 1610,1615,1620,1625,1640, ML 2010,2015,2240,2250,2251,2257,2252 ML 2510,2570,3050A/B,3470 ML 3560,D1630A,2255G,D3470A/B SCX 4321,452,4016,4116,4216,4200, CF550,5800,6800,SF 560,565P,750,755P,3820, Dell 1110		○		○
	MFP	Mono	MLX-1 / S654	SCX6545	SCX 6545/6555, Xerox WC4260	Under development	○		
Canon	Copier	Color	C348C	NPG35(GPR23)	iRC3480,3380,3080,2550(08/04) iRC2880(06/10)	○	○	○	○
		Color	C320C	NPG22(GPR11)	iRC2620(05/07),3220(04/06),3200(03/04),2600	○	○	○	○
	Mono	C200	NPG20(GPR 8)	iR 2000,1600,1500,2010	○	○			
		C202	NPG28(GPR 18)	iR 2116(08/11) iR 2018,2020,2022(07/10) iR 2016(05/11)	○	○			
		C287	NPG25(GPR15)	iR 2230(05/02);iR2270,2830,2870(04/10) iR 3225, 3230(08/09), iR 3025,3030	○	○			
		C330	NPG18 (GPR 6)	iR 200,210,220,330,400,2200,2800,3300,3320 GP 200,210,215,225,405	○	○			
		C357	NPG26(GPR16)	iR 3570,4570(04/10)	○	○			
		C657	NPG27(GPR17)	iR 5070,5570,6570		○			
		C567	NPG36(GPR24)	iR 5055,5065,5075			○		
		C254	NPG50/51(GPR35/GPR34)	iR 2525,2530 iR2535,3545	Under development		○		
		C500	NPG16(GPR4)	iR 5000,5020,6000,6020			○		
C603 (Analogue)	NPG 7 NPG 13	NP 6025,6028,6030,6031,6035,6035F, NP 6225,6230,6235,6335,6340,7340	○						
Xerox	Copier	Color	P6550CN (Black) (Without Gear)	DCC6550	DC C5540,C6550,C7550 ApeosPort C5540,C6550,C7550	○			
		Color	C225C	CT350654 / 013R00647	DCIV C5570,4470,3370,2270 DCIII C4400,4100,3300,2200,2201 WC 7425,7428,7435	○			○
		Color	X400C	CT350150 (Drum unit)	ApeosPort II C2200,3300,4300 Docu Centre C240,250,320,350,400,450 DCII C2200,C3300,C4300 WC 7328,7335,7345,7346	○	○	○	○
	Mono	X321	F440	Able 1220,1321,3180,3221,Hodaka 1 Epson LP9600, EPL N4000,QMS3260,4032	○				
		X286	CT350299 CT350767	Docu Centre 156,186,236,286 Docu Center A285/A235, DC450/550, DC535 DCII 3005/2055/2005, DCIII 2007/3007	○	○	○	○	
	Printers	Color	C225C	CT350654 / 013R00647	DP C2250,2255,3360	○	○		○
			X210C	CT350481~8	Xerox DP C2100, C3210 Xerox Phaser 6180 Epson Aculaser 2800,3800 Dell 3110,3115	○			○
			X354C	CT350462 / 016-1886-00 / 08R00713	DP C2220,2221,3140,3250,3530,3540 DP C4350, Lexmark C935 Phaser 7700,7760(USA)	○	○		○
		Mono	SL-1	P105	P105b, P205b			○	
			P550A	CT350767 113R00670	Phaser 5500,5550 Docu Printer 405, 505 Dell7330, IBM Inforprinter 1585, Tally 9050, Lexmark W840			○	○

Brand	Machine	Color	Product Code	Cartridge Type	Recommended for use In	OPC Drum	Toner	Carrier & Developer	Chips
Toshiba	Copier	Mono	T352	OD3500 / T3500	e-Studio 353,453(08/01);352,452(06/05) e-Studio 350,450(04/01);35,45(01/01)	○	○	○	○
			T230A	T2320 / OD1600	e-Studio 202,203(08/09) e-Studio 233,283(08/01);167,207,237(07/05) e-Studio 282,165,163(06/06);232(05/12) e-studio 161,230,280(04/07) e-Studio 160,200,250(03/03); e-Studio 16S,20S,25S(02/03);25,20,28(01/11) e-Studio 16(00/12)	○	○	○	○
			T206A	OD2060	BD 2060,2860,3560	○		○	
Konica-Minolta	Copier	Color	T652C (Without Gear)	A0600, IU-610	BH C451,C650,C650P,C550	○			
			C250C	IU210	BH C250,252 NEW			○	
			C350C	IU310	BH C350 NEW			○	
		Mono	M450	Di450	Di 450,470,550	○			
			M152A	DR114	KM 7216,7218(04/03),7115,7118(01/12) BH 222(08/09), BH 181,211(07/10),BH180,210(05/09), Di 152,181,183	○			
			M250A	DR310	BH 282,362(09/02),BH361(08/09), BH360(07/03) BH 250,350(05/06), BH200(05/10)	○			
Oki	Printer	Mono	B410	43979101	OKI B410,430,B420dn,B430dn,MB460,MB470,MB480		○		
HP	Printer	Color	H380C	Q6470,Q7581~83	CLJ 2700,3000,3500,3600,3700,3800	○			○
			EP86	C9730~32	CLJ 5500,5500DN,5550 Canon LBP 2710,2810,5700,5800 Image Class 3500	○			○
Dell	Printer	Color	D311C	Dell3110	Dell 3110, 3115, Xerox DP C2100,C3210, Xerox Phaser 6180 Epson Aculaser 2800,3800	○		○	○
Lexmark	Printer	Mono	MLH-3	T640	T640/650 E260/460 NEW		Under development		
Ricoh	Copier		SN602	A1539510 / TYPE 1	FT5035 ,4022,4027,4127,4522,4527,4622,4627,4822 5135,5535,5632,5640,5732,5740,5832,5840	○	○	○	
			SN803	TYPE 410	FT4418 ,4415,4460, FW740,750,760,770,780,830,870	○	○	○	
	Printer	Mono	R115	B0399510	AFICIO 1015,270,220,1018, AFICIO 2015,2016,2018,2020,3025,3030 Gestetner 1502,3222,3227, 1802, DSM615,DSM616,DSM618,DSM620 Lanier5222,5227, LD115,LD116,LD118,LD120, MP1600,MP2000,MP2510,MP2550,MP2851, MP3010,MP3350,MP3351 Savin2515,2518,4015,4018,8016,8020,9922,9927	○			
			C163	411844, TYPE 1515	AFICIO 1515, Gestetner DSM415,416, Lanier LD015,016, AFICIO MP161,171,Savin 3515,816	○			